

Getting Started Guide & FAQs of Solidcom C1 Pro Roaming Hub

Title	Getting Started Guide & FAQs of Solidcom C1 Pro Roaming Hub		Document ID	AS-240808003	
Author	Aaron		Department	Sales & Engineering Department	
Version	V1.0		Update Date	2024-08-29	
Reviewer	@王国琛(王国琛 Zachary)		Review Date		
Security Level			Release Date		
Solidcom C1 Pro Roaming Hub 官网发布资料					
内容更新时间	更新内容	文档更新人	官网更新人	官网更新状态	官网更新时间
2024-08-29	初步分类	Aaron			

Getting Started Guide

1. Hub Installation

- a. The distance between two hubs is at least 1.5 meters when multiple Solidcom C1 Pro Roaming Hub systems are cascaded.
- b. You are advised to install the hub at a place higher than 1.7 meters in an open space. A confined environment may affect the wireless signal quality and reduce the transmission range.



2. Cascade Settings

1. Cascade Within Solidcom C1 Pro Roaming Hub Systems: Cascade via the 4-Wire Interface:

a) Connection:

Use a standard network cable to connect two hubs via the **4-wire** interface. The length of the network cable is up to **300 meters**.



b) 4-Wire Settings:

After connecting two hubs using a network cable, select **4 Wire > Line Sequence Switching** on the hubs, and then select **Standard** on one hub and **Cross** on the other hub.

Cascade via the RJ45 interface:

a) Connection:

Note: Before connect the two hubs via RJ45 ports, please make sure all of the headsets and hubs turned on, and all of the headsets connected to the corresponding Hub already.

Use a standard network cable to connect two hubs via the **RJ45** interface. Either of the two RJ45 interfaces on the hub works. The length of the network cable is up to **100 meters**(Cat 5e) / **200 meters**(Cat 6e).



It does only support 2 hubs connection. On one hub, select **Master Device**, and on another hub, select **Remote Device**.

b) Settings:

After connecting two hubs using a network cable, select **M & R** on the hubs to set the hub mode. On one hub, select **Master Device**. On the other hub, select **Remote Device** > **Scan** and then select the IP address of the corresponding master hub.

Note: The function of obtaining the IP address automatically under **Network** > **Wired Network Setting** needs to be turned off on both two hubs.

Pre-Sales FAQs

1. How Many Groups Does Solidcom C1 Pro Roaming Hub Support?

The Solidcom C1 Pro Roaming Hub system supports 6 groups (Ch1 to Ch6), but with Solidcom C1 or C1 Pro headsets only support 2 groups, A & B buttons can be allocated to any 2 channels from 6.

2. What's the transmission range of the Hub ?

It is 500 meters in omnidirectional.

3. How Many Remote Headsets Can Work with One Hub ?

Up to 20 remote headsets

4. Can the Solidcom C1 and Solidcom C1 Pro headsets work with Solidcom C1 Pro Roaming Hub ?

Yes, it's compatible, just need to make sure all of them work with the latest firmware version.

5. How many sets of Solidcom C1 Pro Roaming Hub-HUB can be cascaded?

2 pcs in maximum with IP cascade mode, and 2 pcs with 4W cascade mode.

6. What does the roaming function means?

It means one headset can connect to two hubs, when the headset moving in the range of two hubs, the headset will switching

connections between two hubs automatically according to the signal strength.

Operation FAQs

1. How to Manage Groups with the Solidcom C1 Pro Roaming Hub System?

The groups can be managed in browser based software or "Hollyvox" APP.

Browser based software:

Use a network cable to connect the hub to a computer via the RJ45 interface and set the IP address of the computer (make sure it is in the same LAN as the hub), open the browser, and then visit **192.168.218.10** (default value that can be modified) to enter the configuration page for the hub.

APP:

Open the "Hollyvox APP", and then add one device to connect to the base station via Bluetooth.

2. How to Use the UAC Function of the Solidcom C1 Pro Roaming Hub Hub?

Connect the hub to a computer using a USB-C to USB-A cable, and then the computer will recognize the hub as an audio device (one channel IN and one channel OUT).

3. Why the headset can not roaming to another Hub when cascade by IP?

- a. Please make sure both of the hubs set as Master and Remote
- b. When the IP cascading over the network switcher or fiber device, the Roaming function will doesn't work anymore.