

# CRANE-M2 S Camera Compatibility List (Dedicated Quick Release Plate)



Update Date: July 21, 2022 Firmware Version: V1.71

V1.20

Camera Brand	Camera Model	Lens Model	Balance Adjustment	Installation Remark	Notes
Sony	α7M2	FE 24mm F2.8 G	√	No need to remove eyepiece cap	-
		FE 28mm F2	√	No need to remove eyepiece cap	-
		FE 35mm F1.8	√	Need to remove eyepiece cap	-
		Sonnar T* FE 35mm F2.8 ZA	√	No need to remove eyepiece cap	-
		FE 40mm F2.5 G	√	No need to remove eyepiece cap	-
		Sigma45mm f/2.8 DG DN	√	No need to remove eyepiece cap	-
		FE 50mm F1.8	√	No need to remove eyepiece cap	-
		FE 50mm F2.5 G	√	No need to remove eyepiece cap	-
		FE 28-60mm F4-5.6	√	Can be balanced at any focal length, no need to remove eyepiece cap	-
	α7R2	FE 24mm F2.8 G	√	No need to remove eyepiece cap	-
		FE 28mm F2	√	No need to remove eyepiece cap	-
		FE 35mm F1.8	√	Need to remove eyepiece cap	-
		Sonnar T* FE 35mm F2.8 ZA	√	No need to remove eyepiece cap	-
		FE 40mm F2.5 G	√	No need to remove eyepiece cap	-
		Sigma45mm f/2.8 DG DN	√	No need to remove eyepiece cap	-
		FE 50mm F1.8	√	No need to remove eyepiece cap	-
		FE 50mm F2.5 G	√	No need to remove eyepiece cap	-
		FE 28-60mm F4-5.6	√	Can be balanced at any focal length, no need to remove eyepiece cap	-
	α7S2	FE 24mm F2.8 G	√	No need to remove eyepiece cap	-
		FE 28mm F2	√	No need to remove eyepiece cap	-
		FE 35mm F1.8	√	Need to remove eyepiece cap	-
		Sonnar T* FE 35mm F2.8 ZA	√	No need to remove eyepiece cap	-
		FE 40mm F2.5 G	√	No need to remove eyepiece cap	-
		Sigma45mm f/2.8 DG DN	√	No need to remove eyepiece cap	-



Camera Brand	Camera Model	Lens Model	Balance Adjustment	Installation Remark	Notes
Sony	α7S2	FE 50mm F1.8	√	No need to remove eyepiece cap	-
		FE 50mm F2.5 G	√	No need to remove eyepiece cap	-
		FE 28-60mm F4-5.6	√	Can be balanced at any focal length, no need to remove eyepiece cap	-
	α7M3	FE 24mm F2.8 G	√	No need to remove eyepiece cap	-
		FE 28mm F2	√	No need to remove eyepiece cap	-
		FE 35mm F1.8	√	Need to remove eyepiece cap	-
		Sonnar T* FE 35mm F2.8 ZA	√	No need to remove eyepiece cap	-
		FE 40mm F2.5 G	√	No need to remove eyepiece cap	-
		Sigma45mm f/2.8 DG DN	√	No need to remove eyepiece cap	-
		FE 50mm F1.8	√	No need to remove eyepiece cap	-
		FE 50mm F2.5 G	√	No need to remove eyepiece cap	-
		FE 28-60mm F4-5.6	√	Can be balanced at any focal length, no need to remove eyepiece cap	-
	α7R3	FE 24mm F2.8 G	√	No need to remove eyepiece cap	-
		FE 28mm F2	√	No need to remove eyepiece cap	-
		FE 35mm F1.8	√	Need to remove eyepiece cap	-
		Sonnar T* FE 35mm F2.8 ZA	√	No need to remove eyepiece cap	-
		FE 40mm F2.5 G	√	No need to remove eyepiece cap	-
		Sigma45mm f/2.8 DG DN	√	No need to remove eyepiece cap	-
		FE 50mm F1.8	√	No need to remove eyepiece cap	-
		FE 50mm F2.5 G	√	No need to remove eyepiece cap	-
		FE 28-60mm F4-5.6	√	Can be balanced at any focal length, no need to remove eyepiece cap	-



Camera Brand	Camera Model	Lens Model	Balance Adjustment	Installation Remark	Notes
Sony	α7M4	FE 24mm F2.8 G	√	No need to remove eyepiece cap	-
		FE 28mm F2	√	No need to remove eyepiece cap	-
		Sonnar T* FE 35mm F2.8 ZA	√	No need to remove eyepiece cap	-
		FE 40mm F2.5 G	√	No need to remove eyepiece cap	-
		FE 50mm F1.8	√	No need to remove eyepiece cap	-
		FE 50mm F2.5 G	√	No need to remove eyepiece cap	-
		FE 28-60mm F4-5.6	√	Can be balanced at any focal length, no need to remove eyepiece cap	-
	α7S3	FE 24mm F2.8 G	√	No need to remove eyepiece cap	-
		FE 28mm F2	√	No need to remove eyepiece cap	-
		Sonnar T* FE 35mm F2.8 ZA	√	No need to remove eyepiece cap	-
		FE 40mm F2.5 G	√	No need to remove eyepiece cap	-
		FE 50mm F1.8	√	No need to remove eyepiece cap	-
		FE 50mm F2.5 G	√	No need to remove eyepiece cap	-
		FE 28-60mm F4-5.6	√	Can be balanced at any focal length, no need to remove eyepiece cap	-



Camera Brand	Camera Model	Lens Model	Balance Adjustment	Installation Remark	Notes
Sony	α7R4	FE 24mm F2.8 G	√	No need to remove eyepiece cap	-
		FE 28mm F2	√	No need to remove eyepiece cap	-
		Sonnar T* FE 35mm F2.8 ZA	√	No need to remove eyepiece cap	-
		FE 40mm F2.5 G	√	No need to remove eyepiece cap	-
		FE 50mm F1.8	√	No need to remove eyepiece cap	-
		FE 50mm F2.5 G	√	No need to remove eyepiece cap	-
		FE 28-60mm F4-5.6	√	Can be balanced at any focal length, no need to remove eyepiece cap	-
	FX3	FE 24mm F2.8 G	√	No need to remove eyepiece cap	-
		FE 28mm F2	√	No need to remove eyepiece cap	-
		Sonnar T* FE 35mm F2.8 ZA	√	No need to remove eyepiece cap	-
		FE 40mm F2.5 G	√	No need to remove eyepiece cap	-
		FE 50mm F1.8	√	No need to remove eyepiece cap	-
		FE 50mm F2.5 G	√	No need to remove eyepiece cap	-
		FE 28-60mm F4-5.6	√	Can be balanced at any focal length, no need to remove eyepiece cap	-
	α7C	FE 20mm F1.8 G	√	No need to remove eyepiece cap	-
		FE 24mm F2.8 G	√	No need to remove eyepiece cap	-
		FE 28mm F2	√	No need to remove eyepiece cap	-
		FE 35mm F1.8	√	No need to remove eyepiece cap	-
		Sonnar T* FE 35mm F2.8 ZA	√	No need to remove eyepiece cap	-
		FE 40mm F2.5 G	√	No need to remove eyepiece cap	-
		Sigma45mm f/2.8 DG DN	√	No need to remove eyepiece cap	-
		FE 50mm F1.8	√	No need to remove eyepiece cap	-
		FE 50mm F2.5 G	√	No need to remove eyepiece cap	-



Camera Brand	Camera Model	Lens Model	Balance Adjustment	Installation Remark	Notes
Sony	α7C	FE 50mm F2.8	√	No need to remove eyepiece cap	-
		Sonnar® T* FE 55mm F1.8 ZA	√	No need to remove eyepiece cap	-
		FE 28-60mm F4-5.6	√	Can be balanced at any focal length, no need to remove eyepiece cap	-
		FE 28-70mm F3.5-5.6 OSS	√	Can be balanced at any focal length, no need to remove eyepiece cap	-
	α6600	FE 20mm F1.8 G	√	No need to remove eyepiece cap	-
		Sonnar T* E 24mm F1.8 ZA	√	No need to remove eyepiece cap	-
		FE 24mm F2.8 G	√	No need to remove eyepiece cap	-
		FE 28mm F2	√	No need to remove eyepiece cap	-
		Sigma 30mm f/1.4 DC DN	√	No need to remove eyepiece cap	-
		Sonnar T* FE 35mm F2.8 ZA	√	No need to remove eyepiece cap	-
		FE 40mm F2.5 G	√	No need to remove eyepiece cap	-
		FE 50mm F1.8	√	No need to remove eyepiece cap	-
		FE 50mm F2.5 G	√	No need to remove eyepiece cap	-
		FE 50mm F2.8	√	No need to remove eyepiece cap	-
		Sonnar T* FE 55mm F1.8 ZA	√	No need to remove eyepiece cap	-
		E 10-18mm F4 OSS	√	Can be balanced at any focal length, no need to remove eyepiece cap	-
		E 16-70mm F4 ZA OSS	√	Can be balanced at any focal length, no need to remove eyepiece cap	-
		FE 28-60mm F4-5.6	√	Can be balanced at any focal length, no need to remove eyepiece cap	-
		FE 28-70mm F3.5-5.6 OSS	√	Can be balanced at any focal length, no need to remove eyepiece cap	-
	α6500	FE 20mm F1.8 G	√	No need to remove eyepiece cap	-
		Sonnar T* E 24mm F1.8 ZA	√	No need to remove eyepiece cap	-
		FE 24mm F2.8 G	√	No need to remove eyepiece cap	-
		FE 28mm F2	√	No need to remove eyepiece cap	-
		Sigma 30mm f/1.4 DC DN	√	No need to remove eyepiece cap	-
		Sonnar T* FE 35mm F2.8 ZA	√	No need to remove eyepiece cap	-
		FE 40mm F2.5 G	√	No need to remove eyepiece cap	-



Camera Brand	Camera Model	Lens Model	Balance Adjustment	Installation Remark	Notes
Sony	α6500	FE 50mm F1.8	√	No need to remove eyepiece cap	-
		FE 50mm F2.5 G	√	No need to remove eyepiece cap	-
		FE 50mm F2.8	√	No need to remove eyepiece cap	-
		Sonnar® T* FE 55mm F1.8 ZA	√	No need to remove eyepiece cap	-
		E 10-18mm F4 OSS	√	Can be balanced at any focal length, no need to remove eyepiece cap	-
		E 16-70mm F4 ZA OSS	√	Can be balanced at any focal length, no need to remove eyepiece cap	-
		FE 28-60mm F4-5.6	√	Can be balanced at any focal length, no need to remove eyepiece cap	-
		FE 28-70mm F3.5-5.6 OSS	√	Can be balanced at any focal length, no need to remove eyepiece cap	-
	α6400	FE 20mm F1.8 G	√	No need to remove eyepiece cap	-
		Sonnar T* E 24mm F1.8 ZA	√	No need to remove eyepiece cap	-
		FE 24mm F2.8 G	√	No need to remove eyepiece cap	-
		FE 28mm F2	√	No need to remove eyepiece cap	-
		Sigma 30mm f/1.4 DC DN	√	No need to remove eyepiece cap	-
		Sonnar T* FE 35mm F2.8 ZA	√	No need to remove eyepiece cap	-
		FE 40mm F2.5 G	√	No need to remove eyepiece cap	-
		FE 50mm F1.8	√	No need to remove eyepiece cap	-
		FE 50mm F2.5 G	√	No need to remove eyepiece cap	-
		FE 50mm F2.8	√	No need to remove eyepiece cap	-
		Sonnar® T* FE 55mm F1.8 ZA	√	No need to remove eyepiece cap	-
		E 10-18mm F4 OSS	√	Can be balanced at any focal length, no need to remove eyepiece cap	-
		E 16-70mm F4 ZA OSS	√	Can be balanced at any focal length, no need to remove eyepiece cap	-
		FE 28-60mm F4-5.6	√	Can be balanced at any focal length, no need to remove eyepiece cap	-
		FE 28-70mm F3.5-5.6 OSS	√	Can be balanced at any focal length, no need to remove eyepiece cap	-
	α6300	FE 20mm F1.8 G	√	No need to remove eyepiece cap	-
		Sonnar T* E 24mm F1.8 ZA	√	No need to remove eyepiece cap	-
		FE 24mm F2.8 G	√	No need to remove eyepiece cap	-



Camera Brand	Camera Model	Lens Model	Balance Adjustment	Installation Remark	Notes
Sony	α6300	FE 28mm F2	√	No need to remove eyepiece cap	-
		Sigma 30mm f/1.4 DC DN	√	No need to remove eyepiece cap	-
		Sonnar T* FE 35mm F2.8 ZA	√	No need to remove eyepiece cap	-
		FE 40mm F2.5 G	√	No need to remove eyepiece cap	-
		FE 50mm F1.8	√	No need to remove eyepiece cap	-
		FE 50mm F2.5 G	√	No need to remove eyepiece cap	-
		FE 50mm F2.8	√	No need to remove eyepiece cap	-
		Sonnar® T* FE 55mm F1.8 ZA	√	No need to remove eyepiece cap	-
		E 10-18mm F4 OSS	√	Can be balanced at any focal length, no need to remove eyepiece cap	-
		E 16-70mm F4 ZA OSS	√	Can be balanced at any focal length, no need to remove eyepiece cap	-
		FE 28-60mm F4-5.6	√	Can be balanced at any focal length, no need to remove eyepiece cap	-
		FE 28-70mm F3.5-5.6 OSS	√	Can be balanced at any focal length, no need to remove eyepiece cap	-
	α6100	FE 20mm F1.8 G	√	No need to remove eyepiece cap	-
		Sonnar T* E 24mm F1.8 ZA	√	No need to remove eyepiece cap	-
		FE 24mm F2.8 G	√	No need to remove eyepiece cap	-
		FE 28mm F2	√	No need to remove eyepiece cap	-
		Sigma 30mm f/1.4 DC DN	√	No need to remove eyepiece cap	-
		Sonnar T* FE 35mm F2.8 ZA	√	No need to remove eyepiece cap	-
		FE 40mm F2.5 G	√	No need to remove eyepiece cap	-
		FE 50mm F1.8	√	No need to remove eyepiece cap	-
		FE 50mm F2.5 G	√	No need to remove eyepiece cap	-
		FE 50mm F2.8	√	No need to remove eyepiece cap	-
		Sonnar® T* FE 55mm F1.8 ZA	√	No need to remove eyepiece cap	-
		E 10-18mm F4 OSS	√	Can be balanced at any focal length, no need to remove eyepiece cap	-
		E 16-70mm F4 ZA OSS	√	Can be balanced at any focal length, no need to remove eyepiece cap	-
		FE 28-60mm F4-5.6	√	Can be balanced at any focal length, no need to remove eyepiece cap	-



Camera Brand	Camera Model	Lens Model	Balance Adjustment	Installation Remark	Notes
Sony	α6100	FE 28-70mm F3.5-5.6 OSS	√	Can be balanced at any focal length, no need to remove eyepiece cap	-
	ZV-E10	FE 20mm F1.8 G	√	No need to remove eyepiece cap	-
		Sonnar T* E 24mm F1.8 ZA	√	No need to remove eyepiece cap	-
		FE 24mm F2.8 G	√	No need to remove eyepiece cap	-
		FE 28mm F2	√	No need to remove eyepiece cap	-
		Sigma 30mm f/1.4 DC DN	√	No need to remove eyepiece cap	-
		Sonnar T* FE 35mm F2.8 ZA	√	No need to remove eyepiece cap	-
		FE 40mm F2.5 G	√	No need to remove eyepiece cap	-
		FE 50mm F1.8	√	No need to remove eyepiece cap	-
		FE 50mm F2.5 G	√	No need to remove eyepiece cap	-
		FE 50mm F2.8	√	No need to remove eyepiece cap	-
		Sonnar® T* FE 55mm F1.8 ZA	√	No need to remove eyepiece cap	-
		E 10-18mm F4 OSS	√	Can be balanced at any focal length, no need to remove eyepiece cap	-
		E 16-70mm F4 ZA OSS	√	Can be balanced at any focal length, no need to remove eyepiece cap	-
		FE 28-60mm F4-5.6	√	Can be balanced at any focal length, no need to remove eyepiece cap	-
		FE 28-70mm F3.5-5.6 OSS	√	Can be balanced at any focal length, no need to remove eyepiece cap	-
	DSC-RX100M5A	Comes with the lens	√	-	Should be powered on to balance
	DSC-RX100M5	Comes with the lens	√	-	Should be powered on to balance
	DSC-RX100M6	Comes with the lens	√	-	Should be powered on to balance
	DSC-RX100M7	Comes with the lens	√	-	Should be powered on to balance
	DSC-WX350	Comes with the lens	√	-	Should be powered on to balance
	DSC-HX90	Comes with the lens	√	-	Should be powered on to balance
	ZV-1	Comes with the lens	√	-	Should be powered on to balance





Camera Brand	Camera Model	Lens Model	Balance Adjustment	Installation Remark	Notes
Canon	EOS R	RF50mm F1.8 STM	√	Do not remove eyepiece cap	-
	EOS RP	RF50mm F1.8 STM	√	Do not remove eyepiece cap	-
	EOS RP	RF35mm F1.8 MACRO IS STM	√	Do not remove eyepiece cap	-
	EOS M50	EF-M 22mm f/2 STM	√	Do not remove eyepiece cap	-
		EF-M 28mm f/3.5 IS STM	√	Do not remove eyepiece cap	-
		EF-M 32mm f/1.4 STM	√	Do not remove eyepiece cap	-
		EF-M 11-22mm f/4-5.6 IS STM	√	Can be balanced at any focal length; Do not remove eyepiece cap	-
		EF-M 15-45mm f/3.5-6.3 IS STM	√	Can be balanced at any focal length; Do not remove eyepiece cap	-
		EF-M 18-55mm f/3.5-5.6 IS STM	√	Can be balanced at any focal length; Do not remove eyepiece cap	-
	M50 Mark II	EF-M 22mm f/2 STM	√	Do not remove eyepiece cap	-
		EF-M 28mm f/3.5 IS STM	√	Do not remove eyepiece cap	-
		EF-M 32mm f/1.4 STM	√	Do not remove eyepiece cap	-
		EF-M 11-22mm f/4-5.6 IS STM	√	Can be balanced at any focal length; Do not remove eyepiece cap	-
		EF-M 15-45mm f/3.5-6.3 IS STM	√	Can be balanced at any focal length; Do not remove eyepiece cap	-
		EF-M 18-55mm f/3.5-5.6 IS STM	√	Can be balanced at any focal length; Do not remove eyepiece cap	-
	EOS M6 Mark II	EF-M 22mm f/2 STM	√	-	-
		EF-M 28mm f/3.5 IS STM	√	-	-
		EF-M 32mm f/1.4 STM	√	-	-
		EF-M 11-22mm f/4-5.6 IS STM	√	Can be balanced at any focal length	-
		EF-M 15-45mm f/3.5-6.3 IS STM	√	Can be balanced at any focal length	-
		EF-M 18-55mm f/3.5-5.6 IS STM	√	Can be balanced at any focal length	-
		EF-M 18-150mm f/3.5-6.3 IS STM	√	Can be balanced at any focal length	-
	EOS 200D	EF 24mm f/2.8 IS USM	√	No need to remove eyepiece cap	-
		EF-S 24mm f/2.8 STM	√	No need to remove eyepiece cap	-
		EF 35mm f/2 IS USM	√	No need to remove eyepiece cap	-



Camera Brand	Camera Model	Lens Model	Balance Adjustment	Installation Remark	Notes
Canon	EOS 200D	EF-S 35mm f/2.8 IS STM MC	√	No need to remove eyepiece cap	-
		EF 50mm f/1.4 USM	√	No need to remove eyepiece cap	-
		EF 50mm f/1.8 STM	√	No need to remove eyepiece cap	-
		EF-S 10-18mm f/4.5-5.6 IS STM	√	Can be balanced at any focal length, No need to remove eyepiece cap	-
	EOS 200D Mark II	EF 24mm f/2.8 IS USM	√	No need to remove eyepiece cap	-
		EF-S 24mm f/2.8 STM	√	No need to remove eyepiece cap	-
		EF 35mm f/2 IS USM	√	No need to remove eyepiece cap	-
		EF-S 35mm f/2.8 IS STM MC	√	No need to remove eyepiece cap	-
		EF 50mm f/1.4 USM	√	No need to remove eyepiece cap	-
		EF 50mm f/1.8 STM	√	No need to remove eyepiece cap	-
		EF-S 10-18mm f/4.5-5.6 IS STM	√	Can be balanced at any focal length, No need to remove eyepiece cap	-
	PowerShot G1X Mark II	Comes with the lens	√	Should be powered on to balance	-
	PowerShot G7X Mark III	Comes with the lens	√	Should be powered on to balance	-
	PowerShot SX720 HS	Comes with the lens	√	Should be powered on to balance	-
Nikon	Z50	NIKKOR Z 28mm f/2.8 (SE)	√	-	-
		NIKKOR Z 35mm f/1.8S	√	-	-
		NIKKOR Z 40mm f/2	√	-	-
		NIKKOR Z 50mm f/1.8	√	-	-
		NIKKOR Z MC 50mm f/2.8	√	-	-
		NIKKOR Z DX 16-50mm f/3.5-6.3 VR	√	Can be balanced at any focal length, no need to remove eyepiece cap	-
		NIKKOR Z 24-50mm f/4-6.3	√	Can be balanced at any focal length, no need to remove eyepiece cap	-
	Z5	NIKKOR Z 28mm f/2.8 (SE)	√	-	-
		NIKKOR Z 40mm f/2	√	-	-
		NIKKOR Z MC 50mm f/2.8	√	-	-



Camera Brand	Camera Model	Lens Model	Balance Adjustment	Installation Remark	Notes
Nikon	Z5	NIKKOR Z DX 16-50mm f/3.5-6.3 VR	√	Can be balanced at any focal length, need to remove eyepiece cap	-
		NIKKOR Z 24-50mm f/4-6.3	√	Can be balanced at any focal length, no need to remove eyepiece cap	-
	Z6	NIKKOR Z 28mm f/2.8 (SE)	√	-	-
		NIKKOR Z 40mm f/2	√	-	-
		NIKKOR Z DX 16-50mm f/3.5-6.3 VR	√	Can be balanced at any focal length, need to remove eyepiece cap	-
		NIKKOR Z 24-50mm f/4-6.3	√	Can be balanced at any focal length, no need to remove eyepiece cap	-
	Z6 II	NIKKOR Z 28mm f/2.8 (SE)	√	-	-
		NIKKOR Z 40mm f/2	√	-	-
		NIKKOR Z DX 16-50mm f/3.5-6.3 VR	√	Can be balanced at any focal length, need to remove eyepiece cap	-
		NIKKOR Z 24-50mm f/4-6.3	√	Can be balanced at any focal length, no need to remove eyepiece cap	-
	Z7	NIKKOR Z 28mm f/2.8 (SE)	√	-	-
		NIKKOR Z 40mm f/2	√	-	-
		NIKKOR Z DX 16-50mm f/3.5-6.3 VR	√	Can be balanced at any focal length, need to remove eyepiece cap	-
		NIKKOR Z 24-50mm f/4-6.3	√	Can be balanced at any focal length, no need to remove eyepiece cap	-
	Z7 II	NIKKOR Z 28mm f/2.8 (SE)	√	-	-
		NIKKOR Z 40mm f/2	√	-	-
		NIKKOR Z DX 16-50mm f/3.5-6.3 VR	√	Can be balanced at any focal length, need to remove eyepiece cap	-
		NIKKOR Z 24-50mm f/4-6.3	√	Can be balanced at any focal length, no need to remove eyepiece cap	-
	Zfc	NIKKOR Z 35mm f/1.8S	√	-	-
		NIKKOR Z 28mm f/2.8 (SE)	√	-	-
		NIKKOR Z 40mm f/2	√	-	-
		NIKKOR Z MC 50mm f/2.8	√	-	-
		NIKKOR Z DX 16-50mm f/3.5-6.3 VR	√	Can be balanced at any focal length, no need to remove eyepiece cap	-
		NIKKOR Z 24-50mm f/4-6.3	√	Can be balanced at any focal length, no need to remove eyepiece cap	-



Camera Brand	Camera Model	Lens Model	Balance Adjustment	Installation Remark	Notes
FUJIFILM	X-T20	XF23mmF2 R WR	√	No need to remove eyepiece cap	-
		XF27mmF2.8	√	No need to remove eyepiece cap	-
		XF56mmF1.2 R	√	No need to remove eyepiece cap	-
		XF14mmF2.8 R	√	No need to remove eyepiece cap	-
		XF16mmF2.8 R WR	√	No need to remove eyepiece cap	-
		XF18mmF1.4 R	√	No need to remove eyepiece cap	-
		XF18mmF2 R	√	No need to remove eyepiece cap	-
		XF 23mm f/1.4 R	√	No need to remove eyepiece cap	-
		XF 35mm f/1.4 R	√	No need to remove eyepiece cap	-
		XF 35mm f/2 R WR	√	No need to remove eyepiece cap	-
		XC 15-45mm f/3.5-5.6 OIS	√	Can be balanced at any focal length, no need to remove eyepiece cap	Should be powered on to balance
		XF 18-55mm f/2.8-4 R OIS	√	Can be balanced at any focal length, no need to remove eyepiece cap	-
	X-A7	XF23mmF2 R WR	√	No need to remove eyepiece cap	-
		XF27mmF2.8	√	No need to remove eyepiece cap	-
		XF56mmF1.2 R	√	No need to remove eyepiece cap	-
		XF14mmF2.8 R	√	No need to remove eyepiece cap	-
		XF16mmF2.8 R WR	√	No need to remove eyepiece cap	-
		XF18mmF1.4 R	√	No need to remove eyepiece cap	-
		XF18mmF2 R	√	No need to remove eyepiece cap	-
		XF 23mm f/1.4 R	√	No need to remove eyepiece cap	-
		XF 35mm f/1.4 R	√	No need to remove eyepiece cap	-
		XF 35mm f/2 R WR	√	No need to remove eyepiece cap	-
		XC 15-45mm f/3.5-5.6 OIS	√	Can be balanced at any focal length, no need to remove eyepiece cap	Should be powered on to balance
		XF 18-55mm f/2.8-4 R OIS	√	Can be balanced at any focal length, no need to remove eyepiece cap	-
	X-T2	XF23mmF2 R WR	√	No need to remove eyepiece cap	-



Camera Brand	Camera Model	Lens Model	Balance Adjustment	Installation Remark	Notes
FUJIFILM	X-T2	XF27mmF2.8	√	No need to remove eyepiece cap	-
		XF56mmF1.2 R	√	No need to remove eyepiece cap	-
		XF14mmF2.8 R	√	No need to remove eyepiece cap	-
		XF16mmF2.8 R WR	√	No need to remove eyepiece cap	-
		XF18mmF1.4 R	√	No need to remove eyepiece cap	-
		XF18mmF2 R	√	No need to remove eyepiece cap	-
		XF 35mm f/1.4 R	√	No need to remove eyepiece cap	-
		XF 35mm f/2 R WR	√	No need to remove eyepiece cap	-
		XC 15-45mm f/3.5-5.6 OIS	√	Can be balanced at any focal length, no need to remove eyepiece cap	Should be powered on to balance
		XF 18-55mm f/2.8-4 R OIS	√	Can be balanced at any focal length, no need to remove eyepiece cap	-
	X-T3	XF16mmF2.8 R WR	√	No need to remove eyepiece cap	-
		XF18mmF2 R	√	No need to remove eyepiece cap	-
		XF23mmF2 R WR	√	No need to remove eyepiece cap	-
		XF27mmF2.8	√	No need to remove eyepiece cap	-
		XF 35mm f/1.4 R	√	No need to remove eyepiece cap	-
		XF 35mm f/2 R WR	√	No need to remove eyepiece cap	-
		XC 15-45mm f/3.5-5.6 OIS	√	Can be balanced at any focal length, no need to remove eyepiece cap	Should be powered on to balance
	X-T4	XF16mmF2.8 R WR	√	No need to remove eyepiece cap	-
		XF18mmF2 R	√	No need to remove eyepiece cap	-
		XF23mmF2 R WR	√	No need to remove eyepiece cap	-
		XF27mmF2.8	√	No need to remove eyepiece cap	-
		XF 35mm f/1.4 R	√	No need to remove eyepiece cap	-
		XF 35mm f/2 R WR	√	No need to remove eyepiece cap	-
		XC 15-45mm f/3.5-5.6 OIS	√	Can be balanced at any focal length, no need to remove eyepiece cap	Should be powered on to balance
	X-S10	XF14mmF2.8 R	√	No need to remove eyepiece cap	-
		XF16mmF2.8 R WR	√	No need to remove eyepiece cap	-



Camera Brand	Camera Model	Lens Model	Balance Adjustment	Installation Remark	Notes
FUJIFILM	X-S10	XF18mmF1.4 R	√	No need to remove eyepiece cap	-
		XF18mmF2 R	√	No need to remove eyepiece cap	-
		XF23mm f/1.4 R	√	No need to remove eyepiece cap	-
		XF23mmF2 R WR	√	No need to remove eyepiece cap	-
		XF27mmF2.8	√	No need to remove eyepiece cap	-
		XF 35mm f/1.4 R	√	No need to remove eyepiece cap	-
		XF 35mm f/2 R WR	√	No need to remove eyepiece cap	-
		XF56mmF1.2 R	√	No need to remove eyepiece cap	-
		XC 15-45mm f/3.5-5.6 OIS	√	Can be balanced at any focal length, no need to remove eyepiece cap	Should be powered on to balance
		XF 18-55mm f/2.8-4 R OIS	√	Can be balanced at any focal length, no need to remove eyepiece cap	-
	X-T30	XF14mmF2.8 R	√	No need to remove eyepiece cap	-
		XF16mmF2.8 R WR	√	No need to remove eyepiece cap	-
		XF18mmF1.4 R	√	No need to remove eyepiece cap	-
		XF18mmF2 R	√	No need to remove eyepiece cap	-
		XF 23mm f/1.4 R	√	No need to remove eyepiece cap	-
		XF23mmF2 R WR	√	No need to remove eyepiece cap	-
		XF27mmF2.8	√	No need to remove eyepiece cap	-
		XF 35mm f/1.4 R	√	No need to remove eyepiece cap	-
		XF 35mm f/2 R WR	√	No need to remove eyepiece cap	-
		XF56mmF1.2 R	√	No need to remove eyepiece cap	-
		XC 15-45mm f/3.5-5.6 OIS	√	Can be balanced at any focal length, no need to remove eyepiece cap	Should be powered on to balance
		XF 18-55mm f/2.8-4 R OIS	√	Can be balanced at any focal length, no need to remove eyepiece cap	-



Camera Brand	Camera Model	Lens Model	Balance Adjustment	Installation Remark	Notes
Panasonic	DC-G100	LEICA DG SUMMILUX 15mm f/1.7 ASPH	√	No need to remove eyepiece cap	-
		Lumix G 25mm f/1.4	√	No need to remove eyepiece cap	-
		Lumix G 25mm f/1.7	√	No need to remove eyepiece cap	-
		LUMIX G MACRO 30mm f/2.8 ASPH MEGA OIS	√	No need to remove eyepiece cap	-
		LEICA DG Vario-Elmarit 8-18mm f/2.8-4.0 ASPH	√	Can be balanced at any focal length, no need to remove eyepiece cap	-
		12-32 0.2m/0.66ft	√	Can be balanced at any focal length, no need to remove eyepiece cap	-
		Lumix G X Vario 12-35mm f/2.8 II ASPH POWER OIS	√	Can be balanced at any focal length, no need to remove eyepiece cap	-
	DMC-GH4	LEICA DG SUMMILUX 15mm f/1.7 ASPH	√	No need to remove eyepiece cap	-
		12-32 0.2m/0.66ft	√	Can be balanced at any focal length, no need to remove eyepiece cap	-
	DMC-GH5	LEICA DG SUMMILUX 15mm f/1.7 ASPH	√	No need to remove eyepiece cap	-
		12-32 0.2m/0.66ft	√	Can be balanced at any focal length, 无No need to remove eyepiece cap	-
	DMC-GH5S	LEICA DG SUMMILUX 15mm f/1.7 ASPH	√	No need to remove eyepiece cap	-
		12-32 0.2m/0.66ft	√	Can be balanced at any focal length, no need to remove eyepiece cap	-
	DMC-LX100M2	Comes with the lens	√	-	Should be powered on to balance
	DMC-LX10	Comes with the lens	√	-	Should be powered on to balance
	DMC-ZS110	Comes with the lens	√	-	Should be powered on to balance
SIGMA	fp	45mm F2.8	√	-	-

# CRANE-M2 S Camera Compatibility List

## (Dedicated Quick Release Plate)

Camera Brand	Camera Model	Lens Model	Balance Adjustment	Installation Remark	Notes
Sony	α7M2	FE 24mm F2.8 G	√	No need to remove eyepiece cap	-
		FE 28mm F2	√	No need to remove eyepiece cap	-
		FE 35mm F1.8	√	Need to remove eyepiece cap	
		Sonnar T* FE 35mm F2.8 ZA	√	No need to remove eyepiece cap	-
		FE 40mm F2.5 G	√	No need to remove eyepiece cap	-
		Sigma45mm f/2.8 DG DN	√	No need to remove eyepiece cap	
		FE 50mm F1.8	√	No need to remove eyepiece cap	-
		FE 50mm F2.5 G	√	No need to remove eyepiece cap	-
		FE 28-60mm F4-5.6	√	Can be balanced at any focal length, no need to remove eyepiece cap	-
	α7R2	FE 24mm F2.8 G	√	No need to remove eyepiece cap	-
		FE 28mm F2	√	No need to remove eyepiece cap	-
		FE 35mm F1.8	√	Need to remove eyepiece cap	-
		Sonnar T* FE 35mm F2.8 ZA	√	No need to remove eyepiece cap	-
		FE 40mm F2.5 G	√	No need to remove eyepiece cap	
		Sigma45mm f/2.8 DG DN	√	No need to remove eyepiece cap	
		FE 50mm F1.8	√	No need to remove eyepiece cap	-
		FE 50mm F2.5 G	√	No need to remove eyepiece cap	-
		FE 28-60mm F4-5.6	√	Can be balanced at any focal length, no need to remove eyepiece cap	-
	α7S2	FE 24mm F2.8 G	√	No need to remove eyepiece cap	-
		FE 28mm F2	√	No need to remove eyepiece cap	-
		FE 35mm F1.8	√	Need to remove eyepiece cap	-
		Sonnar T* FE 35mm F2.8 ZA	√	No need to remove eyepiece cap	-
		FE 40mm F2.5 G	√	No need to remove eyepiece cap	
		Sigma45mm f/2.8 DG DN	√	No need to remove eyepiece cap	





Camera Brand	Camera Model	Lens Model	Balance Adjustment	Installation Remark	Notes
Sony	α7S2	FE 50mm F1.8	√	No need to remove eyepiece cap	-
		FE 50mm F2.5 G	√	No need to remove eyepiece cap	-
		FE 28-60mm F4-5.6	√	Can be balanced at any focal length, no need to remove eyepiece cap	-
	α7M3	FE 24mm F2.8 G	√	No need to remove eyepiece cap	-
		FE 28mm F2	√	No need to remove eyepiece cap	-
		FE 35mm F1.8	√	Need to remove eyepiece cap	-
		Sonnar T* FE 35mm F2.8 ZA	√	No need to remove eyepiece cap	-
		FE 40mm F2.5 G	√	No need to remove eyepiece cap	-
		Sigma45mm f/2.8 DG DN	√	No need to remove eyepiece cap	-
		FE 50mm F1.8	√	No need to remove eyepiece cap	-
		FE 50mm F2.5 G	√	No need to remove eyepiece cap	-
		FE 28-60mm F4-5.6	√	Can be balanced at any focal length, no need to remove eyepiece cap	-
	α7R3	FE 24mm F2.8 G	√	No need to remove eyepiece cap	-
		FE 28mm F2	√	No need to remove eyepiece cap	-
		FE 35mm F1.8	√	Need to remove eyepiece cap	-
		Sonnar T* FE 35mm F2.8 ZA	√	No need to remove eyepiece cap	-
		FE 40mm F2.5 G	√	No need to remove eyepiece cap	-
		Sigma45mm f/2.8 DG DN	√	No need to remove eyepiece cap	-
		FE 50mm F1.8	√	No need to remove eyepiece cap	-
		FE 50mm F2.5 G	√	No need to remove eyepiece cap	-
		FE 28-60mm F4-5.6	√	Can be balanced at any focal length, no need to remove eyepiece cap	-



Camera Brand	Camera Model	Lens Model	Balance Adjustment	Installation Remark	Notes
Sony	α7M4	FE 24mm F2.8 G	√	No need to remove eyepiece cap	-
		FE 28mm F2	√	No need to remove eyepiece cap	-
		Sonnar T* FE 35mm F2.8 ZA	√	No need to remove eyepiece cap	-
		FE 40mm F2.5 G	√	No need to remove eyepiece cap	-
		FE 50mm F1.8	√	No need to remove eyepiece cap	-
		FE 50mm F2.5 G	√	No need to remove eyepiece cap	-
		FE 28-60mm F4-5.6	√	Can be balanced at any focal length, no need to remove eyepiece cap	-
	α7S3	FE 24mm F2.8 G	√	No need to remove eyepiece cap	-
		FE 28mm F2	√	No need to remove eyepiece cap	-
		Sonnar T* FE 35mm F2.8 ZA	√	No need to remove eyepiece cap	-
		FE 40mm F2.5 G	√	No need to remove eyepiece cap	-
		FE 50mm F1.8	√	No need to remove eyepiece cap	-
		FE 50mm F2.5 G	√	No need to remove eyepiece cap	-
		FE 28-60mm F4-5.6	√	Can be balanced at any focal length, no need to remove eyepiece cap	-



Camera Brand	Camera Model	Lens Model	Balance Adjustment	Installation Remark	Notes
Sony	α7R4	FE 24mm F2.8 G	√	No need to remove eyepiece cap	-
		FE 28mm F2	√	No need to remove eyepiece cap	-
		Sonnar T* FE 35mm F2.8 ZA	√	No need to remove eyepiece cap	-
		FE 40mm F2.5 G	√	No need to remove eyepiece cap	-
		FE 50mm F1.8	√	No need to remove eyepiece cap	-
		FE 50mm F2.5 G	√	No need to remove eyepiece cap	-
		FE 28-60mm F4-5.6	√	Can be balanced at any focal length, no need to remove eyepiece cap	-
	FX3	FE 24mm F2.8 G	√	No need to remove eyepiece cap	-
		FE 28mm F2	√	No need to remove eyepiece cap	-
		Sonnar T* FE 35mm F2.8 ZA	√	No need to remove eyepiece cap	-
		FE 40mm F2.5 G	√	No need to remove eyepiece cap	-
		FE 50mm F1.8	√	No need to remove eyepiece cap	-
		FE 50mm F2.5 G	√	No need to remove eyepiece cap	-
		FE 28-60mm F4-5.6	√	Can be balanced at any focal length, no need to remove eyepiece cap	-
	α7C	FE 20mm F1.8 G	√	No need to remove eyepiece cap	-
		FE 24mm F2.8 G	√	No need to remove eyepiece cap	-
		FE 28mm F2	√	No need to remove eyepiece cap	-
		FE 35mm F1.8	√	No need to remove eyepiece cap	-
		Sonnar T* FE 35mm F2.8 ZA	√	No need to remove eyepiece cap	-
		FE 40mm F2.5 G	√	No need to remove eyepiece cap	-
		Sigma45mm f/2.8 DG DN	√	No need to remove eyepiece cap	-
		FE 50mm F1.8	√	No need to remove eyepiece cap	-
		FE 50mm F2.5 G	√	No need to remove eyepiece cap	-
		FE 50mm F2.8	√	No need to remove eyepiece cap	-



Camera Brand	Camera Model	Lens Model	Balance Adjustment	Installation Remark	Notes
Sony	α7C	Sonnar® T* FE 55mm F1.8 ZA	√	No need to remove eyepiece cap	-
		FE 28-60mm F4-5.6	√	Can be balanced at any focal length, no need to remove eyepiece cap	-
		FE 28-70mm F3.5-5.6 OSS	√	Can be balanced at any focal length, no need to remove eyepiece cap	-
	α6600	FE 20mm F1.8 G	√	No need to remove eyepiece cap	-
		Sonnar T* E 24mm F1.8 ZA	√	No need to remove eyepiece cap	-
		FE 24mm F2.8 G	√	No need to remove eyepiece cap	-
		FE 28mm F2	√	No need to remove eyepiece cap	-
		Sigma 30mm f/1.4 DC DN	√	No need to remove eyepiece cap	-
		Sonnar T* FE 35mm F2.8 ZA	√	No need to remove eyepiece cap	-
		FE 40mm F2.5 G	√	No need to remove eyepiece cap	-
		FE 50mm F1.8	√	No need to remove eyepiece cap	-
		FE 50mm F2.5 G	√	No need to remove eyepiece cap	-
		FE 50mm F2.8	√	No need to remove eyepiece cap	-
		Sonnar T* FE 55mm F1.8 ZA	√	No need to remove eyepiece cap	-
		E 10-18mm F4 OSS	√	Can be balanced at any focal length, no need to remove eyepiece cap	-
		E 16-70mm F4 ZA OSS	√	Can be balanced at any focal length, no need to remove eyepiece cap	-
		FE 28-60mm F4-5.6	√	Can be balanced at any focal length, no need to remove eyepiece cap	-
		FE 28-70mm F3.5-5.6 OSS	√	Can be balanced at any focal length, no need to remove eyepiece cap	-
	α6500	FE 20mm F1.8 G	√	No need to remove eyepiece cap	-
		Sonnar T* E 24mm F1.8 ZA	√	No need to remove eyepiece cap	-
		FE 24mm F2.8 G	√	No need to remove eyepiece cap	-
		FE 28mm F2	√	No need to remove eyepiece cap	-
		Sigma 30mm f/1.4 DC DN	√	No need to remove eyepiece cap	-
		Sonnar T* FE 35mm F2.8 ZA	√	No need to remove eyepiece cap	-
		FE 40mm F2.5 G	√	No need to remove eyepiece cap	-



Camera Brand	Camera Model	Lens Model	Balance Adjustment	Installation Remark	Notes
Sony	α6500	FE 50mm F1.8	√	No need to remove eyepiece cap	-
		FE 50mm F2.5 G	√	No need to remove eyepiece cap	-
		FE 50mm F2.8	√	No need to remove eyepiece cap	-
		Sonnar® T* FE 55mm F1.8 ZA	√	No need to remove eyepiece cap	-
		E 10-18mm F4 OSS	√	Can be balanced at any focal length, no need to remove eyepiece cap	-
		E 16-70mm F4 ZA OSS	√	Can be balanced at any focal length, no need to remove eyepiece cap	-
		FE 28-60mm F4-5.6	√	Can be balanced at any focal length, no need to remove eyepiece cap	-
		FE 28-70mm F3.5-5.6 OSS	√	Can be balanced at any focal length, no need to remove eyepiece cap	-
	α6400	FE 20mm F1.8 G	√	No need to remove eyepiece cap	-
		Sonnar T* E 24mm F1.8 ZA	√	No need to remove eyepiece cap	-
		FE 24mm F2.8 G	√	No need to remove eyepiece cap	-
		FE 28mm F2	√	No need to remove eyepiece cap	-
		Sigma 30mm f/1.4 DC DN	√	No need to remove eyepiece cap	-
		Sonnar T* FE 35mm F2.8 ZA	√	No need to remove eyepiece cap	-
		FE 40mm F2.5 G	√	No need to remove eyepiece cap	-
		FE 50mm F1.8	√	No need to remove eyepiece cap	-
		FE 50mm F2.5 G	√	No need to remove eyepiece cap	-
		FE 50mm F2.8	√	No need to remove eyepiece cap	-
		Sonnar® T* FE 55mm F1.8 ZA	√	No need to remove eyepiece cap	-
		E 10-18mm F4 OSS	√	Can be balanced at any focal length, no need to remove eyepiece cap	-
		E 16-70mm F4 ZA OSS	√	Can be balanced at any focal length, no need to remove eyepiece cap	-
		FE 28-60mm F4-5.6	√	Can be balanced at any focal length, no need to remove eyepiece cap	-
		FE 28-70mm F3.5-5.6 OSS	√	Can be balanced at any focal length, no need to remove eyepiece cap	-
	α6300	FE 20mm F1.8 G	√	No need to remove eyepiece cap	-
		Sonnar T* E 24mm F1.8 ZA	√	No need to remove eyepiece cap	-
		FE 24mm F2.8 G	√	No need to remove eyepiece cap	-



Camera Brand	Camera Model	Lens Model	Balance Adjustment	Installation Remark	Notes
Sony	α6300	FE 28mm F2	√	No need to remove eyepiece cap	-
		Sigma 30mm f/1.4 DC DN	√	No need to remove eyepiece cap	-
		Sonnar T* FE 35mm F2.8 ZA	√	No need to remove eyepiece cap	-
		FE 40mm F2.5 G	√	No need to remove eyepiece cap	-
		FE 50mm F1.8	√	No need to remove eyepiece cap	-
		FE 50mm F2.5 G	√	No need to remove eyepiece cap	-
		FE 50mm F2.8	√	No need to remove eyepiece cap	-
		Sonnar® T* FE 55mm F1.8 ZA	√	No need to remove eyepiece cap	-
		E 10-18mm F4 OSS	√	Can be balanced at any focal length, no need to remove eyepiece cap	-
		E 16-70mm F4 ZA OSS	√	Can be balanced at any focal length, no need to remove eyepiece cap	-
		FE 28-60mm F4-5.6	√	Can be balanced at any focal length, no need to remove eyepiece cap	-
		FE 28-70mm F3.5-5.6 OSS	√	Can be balanced at any focal length, no need to remove eyepiece cap	-
	α6100	FE 20mm F1.8 G	√	No need to remove eyepiece cap	-
		Sonnar T* E 24mm F1.8 ZA	√	No need to remove eyepiece cap	-
		FE 24mm F2.8 G	√	No need to remove eyepiece cap	-
		FE 28mm F2	√	No need to remove eyepiece cap	-
		Sigma 30mm f/1.4 DC DN	√	No need to remove eyepiece cap	-
		Sonnar T* FE 35mm F2.8 ZA	√	No need to remove eyepiece cap	-
		FE 40mm F2.5 G	√	No need to remove eyepiece cap	-
		FE 50mm F1.8	√	No need to remove eyepiece cap	-
		FE 50mm F2.5 G	√	No need to remove eyepiece cap	-
		FE 50mm F2.8	√	No need to remove eyepiece cap	-
		Sonnar® T* FE 55mm F1.8 ZA	√	No need to remove eyepiece cap	-
		E 10-18mm F4 OSS	√	Can be balanced at any focal length, no need to remove eyepiece cap	-
		E 16-70mm F4 ZA OSS	√	Can be balanced at any focal length, no need to remove eyepiece cap	-



Camera Brand	Camera Model	Lens Model	Balance Adjustment	Installation Remark	Notes
Sony	α6100	FE 28-60mm F4-5.6	√	Can be balanced at any focal length, no need to remove eyepiece cap	-
		FE 28-70mm F3.5-5.6 OSS	√	Can be balanced at any focal length, no need to remove eyepiece cap	-
	ZV-E10	FE 20mm F1.8 G	√	No need to remove eyepiece cap	-
		Sonnar T* E 24mm F1.8 ZA	√	No need to remove eyepiece cap	-
		FE 24mm F2.8 G	√	No need to remove eyepiece cap	-
		FE 28mm F2	√	No need to remove eyepiece cap	-
		Sigma 30mm f/1.4 DC DN	√	No need to remove eyepiece cap	-
		Sonnar T* FE 35mm F2.8 ZA	√	No need to remove eyepiece cap	-
		FE 40mm F2.5 G	√	No need to remove eyepiece cap	-
		FE 50mm F1.8	√	No need to remove eyepiece cap	-
		FE 50mm F2.5 G	√	No need to remove eyepiece cap	-
		FE 50mm F2.8	√	No need to remove eyepiece cap	-
		Sonnar® T* FE 55mm F1.8 ZA	√	No need to remove eyepiece cap	-
		E 10-18mm F4 OSS	√	Can be balanced at any focal length, no need to remove eyepiece cap	-
		E 16-70mm F4 ZA OSS	√	Can be balanced at any focal length, no need to remove eyepiece cap	-
		FE 28-60mm F4-5.6	√	Can be balanced at any focal length, no need to remove eyepiece cap	-
		FE 28-70mm F3.5-5.6 OSS	√	Can be balanced at any focal length, no need to remove eyepiece cap	-
	DSC-RX100M5A	Comes with the lens	√	-	Should be powered on to balance
	DSC-RX100M5	Comes with the lens	√	-	Should be powered on to balance
	DSC-RX100M6	Comes with the lens	√	-	Should be powered on to balance
	DSC-RX100M7	Comes with the lens	√	-	Should be powered on to balance
	DSC-WX350	Comes with the lens	√	-	Should be powered on to balance
	DSC-HX90	Comes with the lens	√	-	Should be powered on to balance
	ZV-1	Comes with the lens	√	-	Should be powered on to balance



Camera Brand	Camera Model	Lens Model	Balance Adjustment	Installation Remark	Notes
Canon	EOS R	RF50mm F1.8 STM	√	Do not remove eyepiece cap	-
	EOS RP	RF50mm F1.8 STM	√	Do not remove eyepiece cap	-
		RF35mm F1.8 MACRO IS STM	√	Do not remove eyepiece cap	-
	EOS M50	EF-M 22mm f/2 STM	√	Do not remove eyepiece cap	-
		EF-M 28mm f/3.5 IS STM	√	Do not remove eyepiece cap	-
		EF-M 32mm f/1.4 STM	√	Do not remove eyepiece cap	-
		EF-M 11-22mm f/4-5.6 IS STM	√	Can be balanced at any focal length; Do not remove eyepiece cap	-
		EF-M 15-45mm f/3.5-6.3 IS STM	√	Can be balanced at any focal length; Do not remove eyepiece cap	-
		EF-M 18-55mm f/3.5-5.6 IS STM	√	Can be balanced at any focal length; Do not remove eyepiece cap	-
		EF-M 18-55mm f/3.5-5.6 IS STM	√	Can be balanced at any focal length; Do not remove eyepiece cap	-
	M50 Mark II	EF-M 22mm f/2 STM	√	Do not remove eyepiece cap	-
		EF-M 28mm f/3.5 IS STM	√	Do not remove eyepiece cap	-
		EF-M 32mm f/1.4 STM	√	Do not remove eyepiece cap	-
		EF-M 11-22mm f/4-5.6 IS STM	√	Can be balanced at any focal length; Do not remove eyepiece cap	-
		EF-M 15-45mm f/3.5-6.3 IS STM	√	Can be balanced at any focal length; Do not remove eyepiece cap	-
		EF-M 18-55mm f/3.5-5.6 IS STM	√	Can be balanced at any focal length; Do not remove eyepiece cap	-
	EOS M6 Mark II	EF-M 22mm f/2 STM	√	-	-
		EF-M 28mm f/3.5 IS STM	√	-	-
		EF-M 32mm f/1.4 STM	√	-	-
		EF-M 11-22mm f/4-5.6 IS STM	√	Can be balanced at any focal length	-
		EF-M 15-45mm f/3.5-6.3 IS STM	√	Can be balanced at any focal length	-
		EF-M 18-55mm f/3.5-5.6 IS STM	√	Can be balanced at any focal length	-
		EF-M 18-150mm f/3.5-6.3 IS STM	√	Can be balanced at any focal length	-
	EOS 200D	EF 24mm f/2.8 IS USM	√	No need to remove eyepiece cap	-
		EF-S 24mm f/2.8 STM	√	No need to remove eyepiece cap	-
		EF 35mm f/2 IS USM	√	No need to remove eyepiece cap	-





Camera Brand	Camera Model	Lens Model	Balance Adjustment	Installation Remark	Notes
Canon	EOS 200D	EF-S 35mm f/2.8 IS STM MC	√	No need to remove eyepiece cap	-
		EF 50mm f/1.4 USM	√	No need to remove eyepiece cap	-
		EF 50mm f/1.8 STM	√	No need to remove eyepiece cap	-
		EF-S 10-18mm f/4.5-5.6 IS STM	√	Can be balanced at any focal length, No need to remove eyepiece cap	-
	EOS 200D Mark II	EF 24mm f/2.8 IS USM	√	No need to remove eyepiece cap	-
		EF-S 24mm f/2.8 STM	√	No need to remove eyepiece cap	-
		EF 35mm f/2 IS USM	√	No need to remove eyepiece cap	-
		EF-S 35mm f/2.8 IS STM MC	√	No need to remove eyepiece cap	-
		EF 50mm f/1.4 USM	√	No need to remove eyepiece cap	-
		EF 50mm f/1.8 STM	√	No need to remove eyepiece cap	-
		EF-S 10-18mm f/4.5-5.6 IS STM	√	Can be balanced at any focal length, No need to remove eyepiece cap	-
	PowerShot G1X Mark II	Comes with the lens	√	Should be powered on to balance	-
	PowerShot G7X Mark III	Comes with the lens	√	Should be powered on to balance	-
	PowerShot SX720 HS	Comes with the lens	√	Should be powered on to balance	-
Nikon	Z50	NIKKOR Z 28mm f/2.8 (SE)	√	-	-
		NIKKOR Z 35mm f/1.8S	√	-	-
		NIKKOR Z 40mm f/2	√	-	-
		NIKKOR Z 50mm f/1.8	√	-	-
		NIKKOR Z MC 50mm f/2.8	√	-	-
		NIKKOR Z DX 16-50mm f/3.5-6.3 VR	√	Can be balanced at any focal length, no need to remove eyepiece cap	-
		NIKKOR Z 24-50mm f/4-6.3	√	Can be balanced at any focal length, no need to remove eyepiece cap	-
	Z5	NIKKOR Z 28mm f/2.8 (SE)	√	-	-
		NIKKOR Z 40mm f/2	√	-	-
		NIKKOR Z MC 50mm f/2.8	√	-	-



Camera Brand	Camera Model	Lens Model	Balance Adjustment	Installation Remark	Notes
Nikon	Z5	NIKKOR Z DX 16-50mm f/3.5-6.3 VR	√	Can be balanced at any focal length, need to remove eyepiece cap	-
		NIKKOR Z 24-50mm f/4-6.3	√	Can be balanced at any focal length, no need to remove eyepiece cap	-
	Z6	NIKKOR Z 28mm f/2.8 (SE)	√	-	-
		NIKKOR Z 40mm f/2	√	-	-
		NIKKOR Z DX 16-50mm f/3.5-6.3 VR	√	Can be balanced at any focal length, need to remove eyepiece cap	-
		NIKKOR Z 24-50mm f/4-6.3	√	Can be balanced at any focal length, no need to remove eyepiece cap	-
	Z6 II	NIKKOR Z 28mm f/2.8 (SE)	√	-	-
		NIKKOR Z 40mm f/2	√	-	-
		NIKKOR Z DX 16-50mm f/3.5-6.3 VR	√	Can be balanced at any focal length, need to remove eyepiece cap	-
		NIKKOR Z 24-50mm f/4-6.3	√	Can be balanced at any focal length, no need to remove eyepiece cap	-
	Z7	NIKKOR Z 28mm f/2.8 (SE)	√	-	-
		NIKKOR Z 40mm f/2	√	-	-
		NIKKOR Z DX 16-50mm f/3.5-6.3 VR	√	Can be balanced at any focal length, need to remove eyepiece cap	-
		NIKKOR Z 24-50mm f/4-6.3	√	Can be balanced at any focal length, no need to remove eyepiece cap	-
	Z7 II	NIKKOR Z 28mm f/2.8 (SE)	√	-	-
		NIKKOR Z 40mm f/2	√	-	-
		NIKKOR Z DX 16-50mm f/3.5-6.3 VR	√	Can be balanced at any focal length, need to remove eyepiece cap	-
		NIKKOR Z 24-50mm f/4-6.3	√	Can be balanced at any focal length, no need to remove eyepiece cap	-
	Zfc	NIKKOR Z 35mm f/1.8S	√	-	-
		NIKKOR Z 28mm f/2.8 (SE)	√	-	-
		NIKKOR Z 40mm f/2	√	-	-
		NIKKOR Z MC 50mm f/2.8	√	-	-
		NIKKOR Z DX 16-50mm f/3.5-6.3 VR	√	Can be balanced at any focal length, no need to remove eyepiece cap	-
		NIKKOR Z 24-50mm f/4-6.3	√	Can be balanced at any focal length, no need to remove eyepiece cap	-



Camera Brand	Camera Model	Lens Model	Balance Adjustment	Installation Remark	Notes
FUJIFILM	X-T20	XF23mmF2 R WR	√	No need to remove eyepiece cap	-
		XF27mmF2.8	√	No need to remove eyepiece cap	-
		XF56mmF1.2 R	√	No need to remove eyepiece cap	-
		XF14mmF2.8 R	√	No need to remove eyepiece cap	-
		XF16mmF2.8 R WR	√	No need to remove eyepiece cap	-
		XF18mmF1.4 R	√	No need to remove eyepiece cap	-
		XF18mmF2 R	√	No need to remove eyepiece cap	-
		XF 23mm f/1.4 R	√	No need to remove eyepiece cap	-
		XF 35mm f/1.4 R	√	No need to remove eyepiece cap	-
		XF 35mm f/2 R WR	√	No need to remove eyepiece cap	-
		XC 15-45mm f/3.5-5.6 OIS	√	Can be balanced at any focal length, no need to remove eyepiece cap	Should be powered on to balance
		XF 18-55mm f/2.8-4 R OIS	√	Can be balanced at any focal length, no need to remove eyepiece cap	-
	X-A7	XF23mmF2 R WR	√	No need to remove eyepiece cap	-
		XF27mmF2.8	√	No need to remove eyepiece cap	-
		XF56mmF1.2 R	√	No need to remove eyepiece cap	-
		XF14mmF2.8 R	√	No need to remove eyepiece cap	-
		XF16mmF2.8 R WR	√	No need to remove eyepiece cap	-
		XF18mmF1.4 R	√	No need to remove eyepiece cap	-
		XF18mmF2 R	√	No need to remove eyepiece cap	-
		XF 23mm f/1.4 R	√	No need to remove eyepiece cap	-
		XF 35mm f/1.4 R	√	No need to remove eyepiece cap	-
		XF 35mm f/2 R WR	√	No need to remove eyepiece cap	-
		XC 15-45mm f/3.5-5.6 OIS	√	Can be balanced at any focal length, no need to remove eyepiece cap	Should be powered on to balance
		XF 18-55mm f/2.8-4 R OIS	√	Can be balanced at any focal length, no need to remove eyepiece cap	-



Camera Brand	Camera Model	Lens Model	Balance Adjustment	Installation Remark	Notes
FUJIFILM	X-T2	XF23mmF2 R WR	√	No need to remove eyepiece cap	-
		XF27mmF2.8	√	No need to remove eyepiece cap	-
		XF56mmF1.2 R	√	No need to remove eyepiece cap	-
		XF14mmF2.8 R	√	No need to remove eyepiece cap	-
		XF16mmF2.8 R WR	√	No need to remove eyepiece cap	-
		XF18mmF1.4 R	√	No need to remove eyepiece cap	-
		XF18mmF2 R	√	No need to remove eyepiece cap	-
		XF 35mm f/1.4 R	√	No need to remove eyepiece cap	-
		XF 35mm f/2 R WR	√	No need to remove eyepiece cap	-
		XC 15-45mm f/3.5-5.6 OIS	√	Can be balanced at any focal length, no need to remove eyepiece cap	Should be powered on to balance
		XF 18-55mm f/2.8-4 R OIS	√	Can be balanced at any focal length, no need to remove eyepiece cap	-
	X-T3	XF16mmF2.8 R WR	√	No need to remove eyepiece cap	-
		XF18mmF2 R	√	No need to remove eyepiece cap	-
		XF23mmF2 R WR	√	No need to remove eyepiece cap	-
		XF27mmF2.8	√	No need to remove eyepiece cap	-
		XF 35mm f/1.4 R	√	No need to remove eyepiece cap	-
		XF 35mm f/2 R WR	√	No need to remove eyepiece cap	-
		XC 15-45mm f/3.5-5.6 OIS	√	Can be balanced at any focal length, no need to remove eyepiece cap	Should be powered on to balance
	X-T4	XF16mmF2.8 R WR	√	No need to remove eyepiece cap	-
		XF18mmF2 R	√	No need to remove eyepiece cap	-
		XF23mmF2 R WR	√	No need to remove eyepiece cap	-
		XF27mmF2.8	√	No need to remove eyepiece cap	-
		XF 35mm f/1.4 R	√	No need to remove eyepiece cap	-
		XF 35mm f/2 R WR	√	No need to remove eyepiece cap	-
		XC 15-45mm f/3.5-5.6 OIS	√	Can be balanced at any focal length, no need to remove eyepiece cap	Should be powered on to balance



Camera Brand	Camera Model	Lens Model	Balance Adjustment	Installation Remark	Notes
FUJIFILM	X-S10	XF14mmF2.8 R	√	No need to remove eyepiece cap	-
		XF16mmF2.8 R WR	√	No need to remove eyepiece cap	-
		XF18mmF1.4 R	√	No need to remove eyepiece cap	-
		XF18mmF2 R	√	No need to remove eyepiece cap	-
		XF23mm f/1.4 R	√	No need to remove eyepiece cap	-
		XF23mmF2 R WR	√	No need to remove eyepiece cap	-
		XF27mmF2.8	√	No need to remove eyepiece cap	-
		XF 35mm f/1.4 R	√	No need to remove eyepiece cap	-
		XF 35mm f/2 R WR	√	No need to remove eyepiece cap	-
		XF56mmF1.2 R	√	No need to remove eyepiece cap	-
		XC 15-45mm f/3.5-5.6 OIS	√	Can be balanced at any focal length, no need to remove eyepiece cap	Should be powered on to balance
		XF 18-55mm f/2.8-4 R OIS	√	Can be balanced at any focal length, no need to remove eyepiece cap	-
	X-T30	XF14mmF2.8 R	√	No need to remove eyepiece cap	-
		XF16mmF2.8 R WR	√	No need to remove eyepiece cap	-
		XF18mmF1.4 R	√	No need to remove eyepiece cap	-
		XF18mmF2 R	√	No need to remove eyepiece cap	-
		XF 23mm f/1.4 R	√	No need to remove eyepiece cap	-
		XF23mmF2 R WR	√	No need to remove eyepiece cap	-
		XF27mmF2.8	√	No need to remove eyepiece cap	-
		XF 35mm f/1.4 R	√	No need to remove eyepiece cap	-
		XF 35mm f/2 R WR	√	No need to remove eyepiece cap	-
		XF56mmF1.2 R	√	No need to remove eyepiece cap	-
		XC 15-45mm f/3.5-5.6 OIS	√	Can be balanced at any focal length, no need to remove eyepiece cap	Should be powered on to balance
		XF 18-55mm f/2.8-4 R OIS	√	Can be balanced at any focal length, no need to remove eyepiece cap	-



Camera Brand	Camera Model	Lens Model	Balance Adjustment	Installation Remark	Notes
Panasonic	DC-G100	LEICA DG SUMMILUX 15mm f/1.7 ASPH	√	No need to remove eyepiece cap	-
		Lumix G 25mm f/1.4	√	No need to remove eyepiece cap	-
		Lumix G 25mm f/1.7	√	No need to remove eyepiece cap	-
		LUMIX G MACRO 30mm f/2.8 ASPH MEGA OIS	√	No need to remove eyepiece cap	-
		LEICA DG Vario-Elmarit 8-18mm f/2.8-4.0 ASPH	√	Can be balanced at any focal length, no need to remove eyepiece cap	-
		12-32 0.2m/0.66ft	√	Can be balanced at any focal length, no need to remove eyepiece cap	-
		Lumix G X Vario 12-35mm f/2.8 II ASPH POWER OIS	√	Can be balanced at any focal length, no need to remove eyepiece cap	-
	DMC-GH4	LEICA DG SUMMILUX 15mm f/1.7 ASPH	√	No need to remove eyepiece cap	-
		12-32 0.2m/0.66ft	√	Can be balanced at any focal length, no need to remove eyepiece cap	-
	DMC-GH5	LEICA DG SUMMILUX 15mm f/1.7 ASPH	√	No need to remove eyepiece cap	-
		12-32 0.2m/0.66ft	√	Can be balanced at any focal length, 无No need to remove eyepiece cap	-
	DMC-GH5S	LEICA DG SUMMILUX 15mm f/1.7 ASPH	√	No need to remove eyepiece cap	-
		12-32 0.2m/0.66ft	√	Can be balanced at any focal length, no need to remove eyepiece cap	-
	DMC-LX100M2	Comes with the lens	√	-	Should be powered on to balance
	DMC-LX10	Comes with the lens	√	-	Should be powered on to balance
	DMC-ZS110	Comes with the lens	√	-	Should be powered on to balance
SIGMA	fp	45mm F2.8	√	-	-