




- | | |
|---------------------------|--|
| A Shutter Button | I Film Counter Display |
| B Lens | J Neck Strap Loop |
| C Flash | K USB Charging Port & Battery Level Indicator |
| D Viewfinder | L +Button Mode Indicator |
| E Photo Eject Slot | M +Button |
| F Film Door Button | N Light Meter |
| G Flash Button | O Tripod Mount |
| H ON OFF Button | |

Battery

- Battery full
- Battery half full
- Battery empty

+Button

The Polaroid Now+ camera is always ready to connect to the mobile app. Check the connection status with the +Button.

-  Camera is searching for the mobile app.
-  Camera is connected to the mobile app.
-  Camera is not connected to the mobile app.

The lights above the +Button indicate which creative mode you're in.

- Self-timer: Press +Button once to activate.
- Double exposure: Double press +Button to activate.
- Custom shortcut: Long press +Button to activate.



Hello!
Let's start
creating.



Polaroid NOW+ Instant Camera

Generation 2

This camera works with
I-TYPE FILM 600 FILM

Have a problem or
question? Contact our
Customer Support Team

USA/Canada
usa@polaroid.com
+1-212-219-3254

EU/Rest of World
service@polaroid.com
00800 5770 1500 or
visit polaroid.com/help

Quick Start Guide



Download the complete
Polaroid Now+ User Manual.

Read this Quick Start Guide online
www.polaroid.com/nowplus-manual

*The connection is made through the app, so there's no need to pair the camera with your phone. This means the Polaroid Now+ camera will not appear in your phone's list of Bluetooth® devices.
Apple and the App Store logo are trademarks of Apple Inc., registered in the U.S. and other countries and regions. Google Play and the Google Play logo are trademarks of Google LLC. The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by Polaroid International B.V. is under license. Other trademarks and trade names are those of their respective owners.

Made in China for, and distributed by, Polaroid International B.V., 1013 AP, Amsterdam, The Netherlands. POLAROID, the Color Spectrum, and the Classic Border Logo are protected trademarks of Polaroid.
© 2023 Polaroid. All Rights Reserved.

- 1 Turn on the Polaroid Now+ camera by pressing the ON | OFF button.



- 2 To insert the film pack, open the film door.



- 3 Insert the film pack darkslide up and with the tab facing toward you.



- 4 Close the film door. The darkslide covered by the film shield will eject.



- 5 Do not pull on the film shield. Allow it to roll back into the camera, so you can remove the darkslide. You're now ready to take your first photo.



- 6 To add a colored filter from the included kit, press it over the lens. For the starburst and red vignette filters, turn until the small notch aligns with the light meter at the bottom of the lens. The filter will then click into place.



- 7 Download the Polaroid app for extra creative options. Follow the instructions on your mobile phone. The +Button on the camera will turn blue when a connection has been established*.




- 8 When using the Polaroid app, select your mode before continuing to step 9.



- 9 Aim the camera at your subject and press the shutter button. The flash will trigger automatically.



- 10 To shoot without the flash, press the flash button before each shot.



- 11 The photo covered by the film shield will eject.



- 12 Don't shake the photo! Place it in a dark place or face down on a flat surface. Follow the development time on the packaging.

